

### **Quick set-up for continuous mode Monitoring**

- 1) □ Switch the CM2 on, either print out your settings when prompted, or wait for your settings to come up on the display. Follow what you are told to do on the screen; you will then come to the base menu.
- 2) □ If you are monitoring continuously, select number 2 - the unit will come up 'waiting set time' the unit will now start monitoring until you stop it. To stop it, follow the instructions on the screen. Once you are at the base menu it is then safe to switch off the unit. ***It is important that you follow the instructions exactly or you will lose the last events data.*** Alternatively, if you are doing an impulse event select number 1, again follow the on-screen instructions to stop monitoring.
- 3) □ When you have downloaded the data or printed it out and you are happy that you don't need the data in the unit any more it is safe to clear the unit's memory. To do this you select '5' for options, 'menu' for the next options list, '7' - PC Link - Monitor, '2' - clear store, you will be asked are you sure? Enter number for yes then press 8-exit.
- 4) □ ***If you change any settings on the CM2 it is important that you always press 8 – exit, this saves any data that you have changed.***

### **Setting up the TA1**

- 1) □ Place the TA1 on a solid surface, level up using the legs and the spirit bubble on the lid.
- 2) □ Point L - Longitudinal towards the source of the vibration
- 3) □ Plug the TA1 cable into the TA1 lid, making sure it clicks into place, plug the other end into the CM2 marked 'Block A'